


TECHNICAL NOTES

NOTES	CONTENT
GENERAL NOTES	
Metal structure treatment	Use a hammer to bend 5" metal corner bracket around each 2x4. Bore a hole in each bracket, large enough to accept the end of the axle

PROJECT HANDCART	CREATED BY J. ROSCIANO	APPROVED BY A. MORILLO	DATE 31/05/2021	VERSION 1.1
PART NAME TECH NOTES	FILE NAME			PART CODE C1
DEVELOPED BY Unknown	REDESIGNED BY  OHO e.V.	SUPPORTED BY	DOC. TYPE TECH NOTES	MATERIAL
LICENCE CC-BY-SA 4.0		SCALE	QUANTITY SHEET 4 /17	